





How to Change Your Network Name and Password




Safe and Secure

From My Network, tap
your home Wi-Fi network




Safe and Secure

From My Network, tap
your home Wi-Fi network




Safe and Secure

Tap Edit in the upper right corner





Here you can:

- Rename your Wi-Fi network
- Change the Wi-Fi password
- Change the Wi-Fi security




When you're done, tap Save





Connect to Network

Connect to the new network with your password



Connect to Network

All your connected devices will need to be reconnected to this new network



www.brightspeed.com

